

KIT INSTRUCTIONS

Your VISION Oil Analysis kit contains:

- 80 ml sample bottle
- Postal tube
- Sample form with peel-off label
- Sample kit instructions
- Pre-paid return postal bag
- 1 Complete the form.
 In order to provide you with the best analysis and advice,
 please complete each field on the sample information form.
- 2 Remove the label from the form and stick to the sample bottle.
- 3 Take the sample (please fill the bottle 80 ml is required to run all analysis).
- Place the sample bottle inside the postal tube, and place in the pre-paid postal bag addressed to Millers Oils, along with the sample information form.
- 5 Return by post to Millers Oils.

On receipt of your sample, Millers Oils will analyse the oil in its laboratory by testing the physical properties of the oil, identifying any additive depletion and detecting the presence of wear metals or other contaminants. Millers Oils will then send an analysis report to you by e-mail, which will include test results and recommendations based on these results, as well as the information provided on the sample information form. Results will be sent approximately 3-5 working days from receipt of sample.

For help and advice, please contact:

T: +44 (0)1484 475060 E: technical@millersoils.co.uk